

FORD LDM Localization - 错误 #3120

LB Failsafe和正常点灯模式下配置单颗或多颗LED故障检测时，无LED故障时，LB也不能点亮

2024-11-22 11:06 - 娟高

状态:	新建	开始日期:	2024-11-22
优先级:	普通	计划完成日期:	2024-11-25
指派给:		% 完成:	0%
类别:		预期时间:	0.00 小时
目标版本:		耗时:	0.00 小时
描述			
配置：004D7E1041028BA89EFCB228D94300000000000088C10080200000800012D2D2D2D2D008C8C8C8C8C8C8C80040404040404300050505050505BC0800357520006AEA6000D5D50001ABA8107225A5800000000000000000000001111324FD90D 1、用上面配置LB单颗LED故障检测 2、关闭电源，保持LB LED和通道均无故障 3、input Channel1使能（ L/RF_Low_Beam_Ckt置高） 4、进入Failsafe模式，LB无法点亮 （正常点灯用上面配置也会不亮） 配置：004D7E1041028BA89EFCB228D94300000000000088C10080200000800012D2D2D2D2D008C8C8C8C8C8C8C80040404040404300050505050505BC0800357520006AEA6000D5D50001ABA8107225A580000000000000000000000001111524FF94D 1、用上面配置LB多颗LED故障检测 2、关闭电源，保持LB LED和通道均无故障 3、input Channel1使能（ L/RF_Low_Beam_Ckt置高） 4、LB无法点亮 （正常点灯的时候也会出现用上面的配置，LB不点亮情况） 1、仍然使用上面多颗一灭全灭配置 2、关闭电源，制造单颗LB LED故障 3、input Channel1使能（ L/RF_Low_Beam_Ckt置高） 4、LB无法点亮 5、但我配置的是多颗一灭全灭，为何单颗也全灭，并且检测故障是会先亮一下再灭。			